


TOP VIEW OF HEADER AND DOOR AT 90 DEGREES



- NOTES: 1) POSITION DOOR AT 90 DEGREES, DRAW LINES ON BOTTOM OF HEADER TO INDICATE DOOR WHEN OPEN.
2) REED SWITCH MUST BE ACTIVATED BY MAGNET FROM 70 DEGREES THRU 90 DEGREES. THIS SWITCH WILL OPEN THE SUPERSCAN CIRCUIT TO ELIMINATE GUIDE RAIL AND WALL INTERFERENCE.
3) ON PUSH OR INSWING SURFACE APPLIED HEADERS WITH VISABLE ARMS, USE SAME REED SWITCH IN HEADER, WITH MAGNET POSITION ON TOP OF HEADER.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

BEA
We open up New Horizons
HALMA GROUP COMPANY
100 ENTERPRISE DRIVE
PITTSBURGH, PA 15275
PHONE: (412) 249-4100
FAX: (412) 249-4101
EMAIL: www.beasensors.com

TITLE: DOROMATIC ASTROSWING WITH SAFETY SIDE SUPERSCAN CUT-OFF SWITCH

SIZE: A	DRAWN BY: KJG	REV BY: KJG	PART NO: 80.0074.03
	SCALE: NONE	DATE: 07 AUG 05	SHEET 1 OF 1