



NOTES: 1. CONNECTIONS SHOWN IN BOLD ARE THE SYNCH LINES REQUIRED BY TORMAX FOR A SIMULTANEOUS PAIR. SEE TORMAX INSTALLATION MANUAL FOR ASSISTANCE.  
2. SET BODY GUARD OUTPUT CONFIGURATION TO "2".

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION. WEB: WWW.BEASENSORS.COM

**BEA**  
We open up New Horizons  
REALMA GROUP  
COMPANY

100 ENTERPRISE DRIVE  
PITTSBURGH, PA 15275  
PHONE: (412) 249-4100  
FAX: (412) 249-4101  
EMAIL: www.beasensors.com

**TITLE: TORMAX TDA SIMULTANEOUS PAIR  
WITH PARALLAX 2 SYSTEM LO-21P**

SIZE: <b>A</b>	DRAWN BY: WJR	REV BY:	PART NO: 80.0305.01
SCALE: NONE	DATE: 04 DEC 2009	SHEET 1 OF 1	