



- NOTES: 1.) SEE TORMAX INSTALLATION MANUAL FOR ASSISTANCE.  
 2.) ENSURE TO SET THE BODYGUARD RELAY TO VALUE 2. N.C.  
 3.) SEE LO21P USER GUIDE FOR ASSISTANCE

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

**BEA**  
 We open up New Horizons  
 HALMA GROUP COMPANY  
 100 ENTERPRISE DRIVE  
 PITTSBURGH, PA 15275  
 PHONE: (412) 249-4100  
 FAX: (412) 249-4101  
 EMAIL: www.beasensors.com

**TITLE: TORMAX TDA SINGLE DOOR WITH PARALLAX 1 SYSTEM (LO-21P)**

SIZE: A	DRAWN BY: JED	REV BY:	PART NO: 80.0308.00
SCALE: NONE	DATE: 21 JULY 2009	SHEET 1 OF 1	