



- NOTES:**
- 1) SET LZR i30 OUTPUT CONFIGURATION TO "2"
  - 2) SET BR3 TO FUNCTION "10"
  - 3) SET BR3 TIMER "H1" TO 10 SECONDS. THIS WILL BE THE TIME THAT SENSOR MUST BE IN DETECTION BEFORE LIGHT CHANGES!

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

100 ENTERPRISE DRIVE  
PITTSBURGH, PA 15275  
PHONE: (412) 249-4100  
FAX: (412) 249-4101  
EMAIL: www.beasensors.com

**TITLE: LZR i30 W/ BR3 AND DELAYED  
WARNING LIGHT**

SIZE: <b>A</b>	DRAWN BY: WJR	REV BY:	PART NO: <b>80.0360.00</b>
SCALE: NONE	DATE: 08012014	SHEET 1 OF 1	

