



* = L FOR NORMALLY LOCKED RESTROOM
 * = U FOR NORMALLY UNLOCKED RESTROOM

- NOTES:**
- 1) FOR INPUTS 1 & 2 ANY "DRY" CONTACT ACTIVATION DEVICE MAY BE USED.
 - 2) FAIL SAFE FOR NORMALLY LOCKED (WIRE N.O.)
 FAIL SECURE FOR NORMALLY UNLOCKED (WIRE N.C.)
 - 3) CONNECT IN SERIES WITH DOOR POSITION SWITCH WHEN USED WITH RESTROOM CONTROL MODULE
 - 4) ONE POWER SUPPLY CAN BE USED TO POWER ALL DEVICES.
 - 5) KIT DOES NOT INCLUDE POWER SUPPLY, PUSH PLATES, ELECTRIC STRIKE OR DOOR CONTROL.

**IN THE EVENT OF AN EMERGENCY
 PUSH EMERGENCY BUTTON
 AND AUDIBLE AND VISUAL SIGNAL
 WILL ACTIVATE**

EMERGENCY SIGNAGE

TITLE: RESTROOM KIT/ EMERGENCY ADD ON KIT (NORMALLY LOCKED & UNLOCKED)			
SIZE: A	DRAWN BY: WJR	REV BY:	PART NO: 80.0399.00
	SCALE: NONE	DATE: 14 MARCH 2017	SHEET 1 OF 1