

NOTES:

1) FOR INPUTS 1 & 2 ANY "DRY" CONTACT ACTIVATION DEVICE MAY BE USED.

2) FAIL SAFE FOR NORMALLY LOCKED (WIRE N.O.)
FAIL SECURE FOR NORMALLY UNLOCKED (WIRE N.C.)

3) CONNECT IN SERIES WITH DOOR POSITION SWITCH WHEN USED WITH RESTROOM CONTROL MODULE

4) ONE POWER SUPPLY CAN BE USED TO POWER ALL DEVICES.

5) KIT DOES NOT INCLUDE POWER SUPPLY, PUSH PLATES, ELECTRIC STRIKE OR DOOR CONTROL.

IN THE EVENT OF AN EMERGENCY PUSH EMERGENCY BUTTON AND AUDIBLE AND VISUAL SIGNAL WILL ACTIVATE

EMERGENCY SIGNAGE

TITLE: RESTROOM KIT/ EMERGENCY ADD ON KIT (NORMALLY LOCKED & UNLOCKED)

SIZE:	DRAWN BY:	REV BY:	PART NO:
A	WJR		80.0402.00
	SCALE:	DATE:	SHEET
	NONE	23 OCT. 2017	1 OF 1